


Installation Guide




Installation Guide

Degmeda fire tempered wood is installed in a similar way to other timber cladding.

Cladding Fixing

Showing horizontal cladding and vertical battens.



Cladding Fixing

Showing vertical cladding and horizontal battens.




Seasonal Installation

Timber cladding naturally contract in the dry, hot conditions of summer and expand in the rain of winter.




Fix the boards tight to one another in wet, winter conditions when the timber might be moist and prone to shrinkage.




In hot weather when the timber is very dry leave a small expansion gap to allow for timber expansion.

Screw Placement Guideline



Cladding Mounting


Vertical



Horizontal



Diagonal



Screws

Fixing

Should be face screwed without allowing the screw head to penetrate the charred surface. We supply marine grade stainless steel screws for this purpose, with small black heads to give an almost invisible fix. You will need to use 2 screws per fixing point (~40 screws per m2). The length of these screws will be dictated by the depth of the battens you are fixing to.

Screwing distance

2 screws every 500 - 600 mm



Screws

Stainless steel screws only

Screws size

42 mm screw length for

18-20 mm board

Screwing depth

Make sure screw head line is correct

Feel free to contact us for any advice

info@degmeda.eu / +370 627 36 363

FIRE TEMPERED WOOD

Ready for a long life

